

**True dip:** maximum dip angle of a plane measured in vertical section perpendicular to the strike line.

### Determine strike and dip from two apparent dips

**Example:** A fault trace is exposed in two adjacent cliff faces. In one wall the apparent dip is  $15^\circ$ ,  $S50^\circ E$ , and in the other it is  $28^\circ$ ,  $N45^\circ E$  (Fig.1-a). What is the strike and dip of the fault plane?

**Solution: (Fig.1-b)**

1-Use the two trend lines, **OA** and **OC**, as fold lines. Also use a vertical line of arbitrary length **d**.

Draw the two trend lines in plan view.

2-From the junction of these two lines (point **O**) draw apparent dip angle  $\alpha_1$  and  $\alpha_2$ .

3-Draw a line of length (**d=h**) perpendicular to each of the trend lines to form the triangle **COZ** and **AOX**. The value of **d** must always be drawn exactly the same length because it represents the depth to the layer along any strike line.

4- Triangles **COZ** and **AOX** Folded up into plan view with the two apparent-dip trend lines used as fold lines. In Fig.1-b, line **AC** is horizontal and parallel to the fault plane; therefore, it defines the fault's strike.

5-Line **OB** is then plotted perpendicular to line **AC**; it represents the direction of true dip.

6-Using line **OB** as a fold line, triangle **BOY** (Fig.1-b) can be projected into the horizontal plane, again using length **d** to set the position of point **Y**. The true dip can now be measured directly.




Fig.1 :(a) Block diagram. (b)Block diagram showing triangles involved in orthographic projection and trigonometric solutions

**Exercise: Find the true dip and strike for the following pairs of app. dips.**

First app. dip

Second app.dip

-----

-----

a)  $078^\circ/28^\circ$

$S05W^\circ/24^\circ$

b)  $N87^\circ W/31^\circ$

$N61^\circ E/18^\circ$  ..... (H.W.)